ITSU 神手の物



User Manual IS4018使用手冊

CONTENTS

Safety Instructions	2
Warranty Claims	4
Product Parts	5
Moving the Chair	6
Controller Diagram	7
Product Operation Guide	8
Product Features	17
Cleaning And Maintenance	18
Questions And Answers(Q&A)	19
Troubleshooting	20
Product Specification	22
Contact Us	24

Safety Instructions

Warning!

The plug must be fully inserted into an appropriate outlet. Improper connection of the equipment-grounding conductor can result in the risk of electric shock.

Check with a qualified electrician and service personnel if you are in doubt as to whether the product is properly grounded. Do not modify the product's accompanying plug. If the outlet is not suitable, be sure to have a proper outlet installed by a qualified electrician.

When using the massage chair, basic precautions should always be followed to reduce the risk of electric shock, burns, fire, or injury.

Read the following details before use:

- 1. Be sure to insert the massage chair plug into the proper electrical outlet.
- 2. Make sure that the power plug is securely inserted into the proper electrical outlet to reduce the risk of short-circuit and fire.
- 3. Always unplug the massage chair from the electrical outlet immediately after use and before cleaning.
- 4. Do not use the massage chair in places where the humidity is high.
- 5. Do not use the massage chair outdoors and avoid places with direct sunlight.
- If the power goes off during use, be sure to turn the power switch to the OFF position and pull the power plug out from the socket to prevent any damages when the power comes back.
- 7. Never operate the massage chair if the power cord is wet or damaged.
- 8. Never plug/unplug the power cord from the socket with wet hands.
- 9. Close and continuous supervision is necessary when this appliance is used by or near children, invalids or disabled persons.
- 10. Use this appliance only as described in this user manual.
- 11. Do not use any attachments other than those recommended by ITSU.
- 12. Do not stand, sit or jump in the calves rest when the massage chair is in use. This may result in an accident or injury.
- 13. Do not attempt to stand on the backrest and armrest .This may result in an accident or injury.
- 14. Be careful not to fall asleep during the massage.

Safety Instructions


- 15. Always keep the massage chair clean and never insert any object into the gaps on and around the massage chair.
- 16. Do not remove the massage chair by pulling the power supply cord.
- 17. Be sure to check that there is no one (children in particular), pets or obstacles under the massage chair prior to lowering the leg rest /backrest.
- 18. Always check whether the surface of the massage chair is torn or ripped before use. If you find any unfamiliar tears in any area of the cloth in the backrest, do not use the massage chair. Kindly contact ITSU service center immediately for repairs.
- 19. This appliance is designed for household use only.
- 20. For those suffering from illnesses, please consult your doctor on whether you can use the massage chair if in doubt.
- 21. The following persons are requested to consult a doctor prior to use in order to reduce the risk of the user feeling sick or suffering from an injury:
 - Those who have a malignant tumor;
 - Those who suffer from heart disease;
 - Those who are experiencing pregnancy, menstruation and puerperal;
 - Those who require complete rest;
 - Those who are under medical treatment;
 - Those who suffer from back problems or whose backbone is abnormal or bent.
- 22. If you experience pain during use, stop the massage chair immediately. If any injuries happen, consult a doctor immediately. ever massage on swollen or inflamed parts of the body.
- 23. This product is a non-professional appliance designed to provide a comfortable massage. Do not use this product as a substitute for medical treatment.
- 24. Do not use this massage chair for more than 30 minutes at one time and kindly limit the massage to a concentrated area for not more than 15 minutes. Over-massaging can result in overheating, and thus reducing the product's lifespan.
- 25. Do not operate where aerosol (spray) products are used or where oxygen is being administered.
- 26. The massage chair is not suitable for children aged 12 years old and below.


- 27. If the power plug is damaged, it must be replaced by a special plug available from ITSU or authorized agents.
- 28. As a safety precaution, Motor will stop working automatically (for protection) if apply too strong external force during use. Once appear above, switch OFF power, and switch ON again after 10 seconds. Please pay attention to this, especially for user whose weight over 100KG.
- 29. The appliance has a heated surface. Persons insensitive to heat must be careful when using the appliance.
- 30. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved

Warranty Claims

- 1. Warranty is not transferable.
- 2. This warranty is effective only if the product is purchased from ITSU.
- 3. Proof of purchase (original receipt) is required for all warranty repairs.
- All implied warranties, including but not limited to these implied warranties of fitness and merchantability, are limited to the duration stated in the warranty policy.
- 5. Damage due to misuse, improper treatment and unauthorized modification and repair are not covered by this warranty.
- 6. Warranty does not cover accessories and attachments which do not belong to the massage unit.
- 7. Warranty is not effective to rental, business, commercial, institutional or other non-residential users.
- 8. All services covered by this warranty must be approved by ITSU and repaired by authorized technicians only.
- 9. If replacement parts for defective materials are not available, ITSU reserves the right to make substitution in lieu of repair or replacement.

Product Parts






- Total 5 air valves (5 individual massage mechanism)
- A combination of 24 airbags

Moving the Chair


As illustrated, first push the backrest downwards, and then tilt the massage chair onto its wheels to approximate 45 degree to easily mode the chair around the hosue a light pull or push.



Caution:

- 1.Do not move the massage chair when it is occupied.
- 2.Unplug the massage chair cable from power source.
- 3.Do not drop or suddenly let go of the chair when moving as it may damage the chair.
- 4. Two person participation is recommended.
- 5. Placing a mat underneath the massage chair is advisable, as moving process might induce scratches on the floor.

Controller Diagram



Product Operation Guide

Function description of controller buttons.



: Press to turn ON the massage chair.
Press again to turn OFF the massage chair.



: Press to PAUSE the massage chair. Press again to RESUME.



Timer: each press represent an incremental of 3 minutes. adjustable from 3 to 30 minutes, default is 15 minutes.

Position adjustment area:



Press to go to Zero-GI position.

Press again to Zero-GII position.

Press again to Zero-GⅢ position.

Press again to return to default position.

Zero-GII \rightarrow Zero-GIII \rightarrow Default Position



Press to enable SWING function, massage chair will begin to swing at preset interval.



Press to go to initial state.





Press and hold to incline or decline backrest.

p/s:these buttons are not available during Stretching program.

Auto mode:

There are 11 AUTO program.



SPINE CARE



NECK CARE



DEEP



LUMBAR CARE



GENKI



RELAXATION

SHAPE & TONE






CIRCULATION




If you use it continuouslly, please have 10 minutes rest in order to lessen the burden to the body.

Manual mode:

: Press to adjust air intensity. There are 6 levels.




: There are 5 manual massage modes.





9



:Press to enable Heat.

APP Installation

1. Compatible with the following mobile operating system:







IOS 13

Android 10

10

Bluetooth 4.0

- 2. Turn on your mobile phone's bluetooth and WIFI or 3G/4G.
- 3. Scan the QR below to install ITSU WORLD app.





Android

IOS

Interface of APP and descriptions

Switch ON the remote controller, HOME screen page will be displayed. Please choose your desire features. An extra auxillary HOME screen is also available with comprehensive features.





Body Analyzing





- 1.Body analyzing
- Once completed, user are given anoption (in8seconds) to fine tune's houlder position' according to user needs.

AUTO





 There are 11 specially designed automatic programs as described above. AUTO programs default timer is 15 minutes.

Product Operation Guide





Select SIGNATURE, to enter into 4 specially designed signature auto program.

MANUAL



- 7 massage modes: Kneading 1, Kneading 2, Tapping 1, Tapping 2, Clapping 1, Clapping 2, and Rolling.
- 6 levels of Massage Speed/Strength setting.

EXTRA









Additional features are group under EXTRA interface.

SETTING



• 4 languages are available to choose: Chinese, English, Janpanese and Malay.

13

- Bluetooth On/Off.
- (1) Sound : On/Off.

Product Operation Guide

Interface 1:



- 1. Home button
- 2. Massage Indication
- 3. Timer setting
- 4. Massage program shortcut button
- 5. Massage strength: 6 adjustable levels
- 6. Air massage strength: 6 adjustable levels
- 7. PLAY/PAUSE button

Interface 2:




- 1. Backrest incline/decline
- 2. Zero G position selection
- 3. Swing modes selection
- 4. Upright position

Interface 3:



- 1. Gear box roller upward/d own ward adjust
- 2. Spot massage function
- 3. Gear box width adjust
- 4. Massage area selection (for manual massage only).

Wrist band SYNC






Click wrist band icon to begin data synchronization. Once completed, Al will recommend some programs. Please choose one program to start massage. In the event where synchronization is fail (maybe due to bluetooth not connected, no wrist band found or etc), a window will pop up. Kindly rectify the problem and re-synchronize again.


15

Product Operation Guide

After use



- Switch OFF the massage chair to return back to original position.
- Please check surronding, paying special attention to children or pets that may be located in close proximity, before adjusting massage chair backrest/footrest angle.
- Please make sure arms and legs are away from gaps to prevent any possible injury.



- 2.Press POWER button (located at the bottom back of the massage chair) to turn OFF the massage chair and restore the remote controller back to the storage compartment.
- 3. Turn OFF Main switch and unplug from power outlet.
- Do not pull the power cord to remove the plug.
- Do not unplug with wet hands.

Product Features

ITSU massage Chair is controlled by a microcomputer that performs various intelligent massage methods and combinations, like Kneading, Tapping, Shiatsu, Clapping, Rolling, Footroller and Air Massage. All these massage methods accurately capture the acupressure points that could alleviate fatigue, promote metabolism and improve blood circulation effectively. Equipped with eight of full body automatic program, this product thoroughly fulfills your various needs.

Various types of manual / auto massage to suit your needs.

Spring-styled massage that is specially structured for the back is designed according to the curve of the human body to provide a more effective and thorough massage.

- 1. Designed according to body curve, to provide better massage sensations.
- The Timer Function can be adjusted according to your desired duration of the massage programmer.
- 3. User friendly operation.
- 4. Built in with power surge and automatic temperature sensor for safety.
- 5. The operation is controlled by an intelligent microprocessor for excellent performance and consistent quality.
- 6. The machine radiates heat on the surface, Do Not use it over sensitive skin areas or in poorly-ventilated areas.

17

Cleaning And Maintenance

Cleaning of the synthetic leather

Wipe the synthetic leather with a soft dry cloth.

- Do not clean the product with chemicals such as thinners gasoline and alcohol.
- When using a leather maintenance product(cleaning cloth) sold on the market, follow its directions for use.
- If the synthetic leather is very dirty, wipe it with the method below.
 - 1. Put a piece of soft cloth into water or 3% to 5% neutral detergent contained hot water and wring it out.
 - 2. Wip surface of the synthetic leather with the soft cloth.
 - 3. Wipe the detergent with a piece of cloth once soaked in clean water and wrung out.
 - 4. Wipe with a piece of wrung soft cloth.
- 5. Have the synthetic leather take natrual air drying.
- If it is difficult to remove the stains on the synthetic leather, soak a piece of melamine foam bought from the market into a neutral detergent and use it wipe the product.
- Do not dry the surface by a hair drite.
- Surface of the synthetic leather may be dyed by fabric colors; therefore,be careful when wiping the product with denim or colored cloth.
- Keep these positions from long-time contact with plastics to avoid fading.
- Synthetic leather may discolor, so the position in contact with the hair dye used should be covered by a towel.









Cleaning of the plastic parts

- Put a piece of solt cloth into water or neutral detergent contained hot water,wring it out and wipe the plastic parts.
- Do not clean the product with chemicals such as thinners, gasoline and alcohol.
- Wipe witg a piece of cloth once soaked in clean water and wrung out.
 - Wring the cloth out before using it to wipe the remote controller.
- Have the plastic parts take natural air drying.







Questions and answers(Q&A)



Can persons paying frequent visits to hospitals because of diseases use the product?




These persons should consult physicians before using the product.

Massage is the so-called "touch-pressure stimulation": Muscles are compressed to relieve their tension and promote hemokinesis. Some diseases may get worsened because of massage. Thus, consult the attending doctors before using the product.



How about the body height requirement for use of the product?



If a person shorter than 145 centimeters or taller than 185 centimeters uses the upper body massage function and the Lower Leg/Foot massage function of the product at the same time, it will be possible that his soleswill have poor contact with the foot massage section or that his knees will need to be bent.

For a taller person with knee bending when using the product:

Select method (A)

▲ Tilt the backrest and lower the Lower Leg/Foot massage section.

For a short person difficult to touch the foot massage section:

Select method (A)

A Raise the backrest and lift the Lower Leg/Foot massage section.



Are there any things needing special attention during moving?

Pay attention to the following things A during moving.

For convenience during moving, tilt backrest of the product till the lowest position. During handling, do not sit on the product.

1) Press ON button power on the product.





②Press on to make the backrest completely

Press and hold on these two buttons until backrest and footrest stop.

- 3 Turn off the power switch and pull out the power plug.
- If the original packing box is unavailable, make sure the power line is not wound on the product, wind it and place it on the seat surface. When handling the product, keep the power line from falling off and rubbing with ground.
- If the original packing box is unavailable, properly keep other packing auxiliary materials and wrap the product with them to avoid scratch and vibration during handling.

19



I care about the sounds the product makes when being used.



It is caused by the core structure.



Does it matter if the massage wheels have different massage intensities?



This phenomenon possibly exits during massage because of the core structure.

To simulate the most natural massage effect, the product is designed with a core structure allowing alternate back massage by a left massage wheel and a right massage wheel. During massage, the massage wheels possibly have slightly different positions on the back. That's why you have that feeling. It is not a

Troubleshooting

After a fault happens, inspect and try the corresponding method below.

If the fault still exists after that, contact the shop from which you bought the product.

Fault

The massage wheels stop during use

The backrest can not recline up and down or the footrest can not be

lifted up and down

The massage wheels cannot reach the shoulders or the neck

The left and right massage wheels have different heights (intensities)

The product cannot run at

No warm feeling in backrest

The power supply cannot be connected even if is pressed again after the massage

The product is damaged

The power line or the power plug has abnormal heating

Cause and elimination method

For safety, the massage wheels will possibly stop upon a too large external force during use.

At this point, you need to adjust your sitting position, and don't put your back completely on the backrest. (Pay attention to the relevant precautions, especially when used by customer whose weight is 100 Kg or more.)

For safety, the product will stop upon an obstruction or a too large force.

If all contents and buttons are flickering and the backrest or the footrest has stopped, turn off the power supply and turn it on about 10 seconds later and then operate the product.

If the head is not in contact with the headrest, or the back is not in contact with the backrest, the shoulder position in body type detection will possibly be lower than the actual position. Sit in the deepest position of the product, lean your head on the headrest and operate from the beginning again.

It is not a fault but a normal phenomenon because the product is provided with a massage core allowing alternate beats of the massage wheels.

- The power line is disconnected.
- The power switch is not turned on.
- No program is selected after ______ on the remote controller is

The heating button is set to be OFF.

The warm feeling depends on factors such as body type. massage method, clothes and room temperature. Please keep back close to the heat-sensing conduction part to make the custoner feel warm.

The program will terminate about 10 seconds after the massage has ended. Press 💍 at least 10 seconds after all the movements have stopped.

To avoid accidents, contact an authorized service center.

Troubleshooting

The sounds and feelings you care about in use of the product

You will hear or have the following sounds or feelings when using the product. It is not abnormal phenomena but results of the product structure.

- Sound when the stretching massages are retracted
- Sound and feeling when the massage wheels rub patterns on the fabric
- Sound of movements such as kneading and beat
- Friction sound of the running massage wheels
- Sound of up-down movement
- Sound of the conveyor belt
- Motor sound
- Friction sound between the armrests and the back cushion when the backrest is tilting
- Friction sound between the massage wheels and the fabric
- Sound of the inflator pump during Air Bag massage
- Sound of air exhaust during Air Bag massage
- Running sound of the solenoid valve at bottom of the product during Air Bag massage.
- Swing of the footrest
- Running sound of the air bags
- Sliding sound of the foot massage section

If the sound is loud, it is also possible that the product has failed.

• In this case, have the product inspected and repaired by an authorized service center.

⚠ Warning

 Do not refit, disassemble or repair the product without permission.
 Otherwise fires, abnormal movements or personal injuries may happen.

⚠ Warning

- In the case of any abnormality or fault, stop the product immediately and pull out the power plug to avoid fuming, fires and electric shocks.
- < Abnormality and fault examples>
- The product fails to work after the power switch is turned to the ON position;
- After the power line is moved, the product is discontinuously powered on;
- In use, the product gives off a burning smell or an abnormal sound;
- The product is deformed or abnormally heating
 In any of these abnormalities and faults, have the product inspected and repaired by an

authorized service center immediately.

Product Specifications


Power supply		AC220-240V~,50/60Hz
Power consumption		100W
Automatic power-off		Approx. 30 minutes
Dimension	When it is not tilting (L x W x H)	Approx. 1420mm x 740mm x 1170mm
	When it is tilting (LxWxH)	Approx. 1650mm x 740mm x 920mm
Weight		Approx. 65kg
Dimensions of packing box (L x W x H)		1590mm x 765mm x 875mm
Weight(including the packing box)		Approx. 78kg
Operating Conditions		Ambient temperature:Approx.0°C~35°C Relative humidity:Approx.20%~80%
Storage Conditions		Ambient temperature:Approx5°C~35°C Relative humidity:Approx.20%~80%
Maximum body weight of user		Approx. 120kg
Entrance size		Minimum 74cm





For a user heavier than 100 kilograms, the product may have bigger noise and its fabric housing may be worn quicker.

Product Specifications



23

Contact Us



ITSU World Sdn Bhd 13 Lorong Teknologi B. Nouvelle Industry Park. Taman Sains SG1 Kota Damansara. PJU 5. 47810 Petaling Jaya Malaysia

Tel: +603 6732 3722



ITSU World(HK) Limited
Workshop D1,28/F. TML Tower
No. 3 Hoi Shing Road, Tsuen Wan, N.T.

Tel: +852 3611 2228



PT Healthy World Lodan Center Block O No 20 Jalan Lodan Raya No 2 Jakarta Utara 14430

Tel: +62 21-6983 1123

目錄

安全説明	26
保修權限	28
產品部件	29
產品移動説明	30
控制器	31
操作説明	32
功能特點	41
清洗及保養	42
疑問解答(Q&A)	43
故障維修	44
産品規格	46
聯絡我們	48

安全説明

警告!

此按摩椅必須使用與插頭相配的插座。不正確的接地將會導致觸電危險的發生。請不要擅自改裝插頭或插座,務必委託專業的技術人員進行檢查。

使用電器產品時,為減少觸電、灼傷、火災、或人員傷害的危險,應遵守基本安全預防措施,包括以下內容:

在使用前請閱讀所有的使用説明。

- 1. 務必使用與插頭相配的插座。
- 2. 一定要確保插頭完全插入插座內,以減少短路或火災危險。
- 3. 在使用後或清潔前,請務必及時拔掉插頭。
- 4. 請勿在高濕度的環境下使用本產品。
- 5. 請勿在室外或陽光直射的地方存放或使用本產品。
- 6. 如果在使用過程中突然停電,請立即將開關撥至「O」的位置,且拔掉插頭,以免來 電時損壞本產品。
- 7. 當電源線潮濕或損壞時請勿使用按摩椅。
- 8. 請勿用濕手插入和拔掉插座,以免發生意外。
- 9. 當小孩、傷殘人士、行動不便者在按摩椅附近或使用按摩椅時,一定要有人在場看 護。
- 10. 只能將本產品用於本説明書中闡述的用途。
- 11. 不要使用非 ITSU 推薦的附件。
- 12. 在使用過程中請勿坐在按摩椅小腿上,以免導致意外。
- 13. 請勿試圖站在扶手或靠背上,以免按摩椅發生傾倒從而導致意外。
- 14. 按摩過程中請勿進入睡眠狀態。
- 15. 請經常保持按摩椅清潔,避免將其他物體插入按摩椅的縫隙中。
- 16. 請勿直接透過拉扯電源線來移動按摩椅。
- 17. 請確保當降低小腿或靠背時,其下方無其他物體,特別是小孩。
- 18. 請在每次使用前,檢查按摩椅靠背絨布等處是否有異常裂縫。如有異常,請勿使用並即時聯繫 ITSU 售後服務中心。
- 19. 本產品僅為居家使用而設計。
- 20. 當您無法確定自己是否能使用按摩椅時,請先諮詢醫師。

安全説明

- 21. 為避免因使用此按摩椅而導致不適或傷害,以下人士在使用本產品前應諮詢醫師:
 - 患有惡性腫瘤者
 - 患有心髒病者
 - 孕婦、產婦或月經期者
 - 需要安靜休息者
 - 正在接受治療者
 - 有背部疾病者,脊椎異常或扭曲者
- 22. 如在使用過程中覺得疼痛,請立即停止使用;如果在使用過程中受到損傷,請立即 就醫。
- 23. 本產品僅為家庭提供舒適的按摩享受,並非專業的按摩醫療機械,因此不能代替專業的治療。
- 24. 建議每天使用按摩椅的時間為 30 分鐘,按摩同一部位時間不宜超過15分鐘,否則過度按摩會導致適得其反的效果,而且長時間使用會導致按摩椅過熱並縮短產品使用 畫命。
- 25. 請勿在噴氣體溶膠或輸氧的環境中使用本產品。
- 26. 12歲或以下兒童不適宜使用本產品。
- 27. 如果電源線損壞,必須使用 ITSU或合法代理商所提供的專用電源線。
- 28. 使用過程中若施加過大的外力,爲安全起見,機芯會自動停止以保護。當出現該情况時, 先切斷整機電源,10秒后再接通電源進行操作。特別是體重超過100KG的用户,使用時 要特別注意。
- 29. 該設備具有加熱表面,對熱不敏感的人一定要小心使用設備
- 30. 此設備可以讓年齡從8歲以上兒童,肢體,感官或心智能力有缺陷,或者缺乏經驗知識的人使用,如果他們被監督,或者有經過有關使用本產品安全的方式和理解其危害性的指導。

保修權限

- 1. 本保修權限不可轉讓。
- 2. 本保修服務僅對在ITSU購買的產品有效。
- 3. 當要求保修服務時,請出示購買證明(正本收據)。
- 所有保修項目,包括但不限於這些健身及適銷性的保修項目有效期限需視保修政策 而定。
- 5. 因錯誤使用、處理不當以及未經授權私自改裝和維修產品而導致的損壞,不屬於保 修範圍。
- 6. 此保修範圍不包括不屬於產品本身的附件。
- 7. 此保修範圍不適用於租憑、交易、商業、機構或其他非住宅用戶。
- 8. 此保修範圍內所涉及的維修服務需經過 ITSU 授權,且必須由授權的技術人員維修。
- 9. 若需更換的維修附件缺貨,ITSU有權採用替代配件進行維修。

產品部件






- 一共5個氣閥(5個獨立的按摩機制)。
- 24個氣囊组合。

產品移動説明

如圖所示,首先向下推動靠背,然後將按摩椅傾斜約45度,輕輕地拉動或推動椅子。



注意:

- 1.當按摩椅在使用時,請不要移動椅子。
- 2.請把按摩椅電源線從電源上拔下。
- 3.在移動時請勿讓掉落或突然放開椅子,否則可能會損壞椅子。
- 4.建議兩個人參與。
- 5.建議在按摩椅下方放置墊子,因為移動過程中可能會在造成地板划痕。

控制器



操作說明

遙控器按鍵功能描述



:按此鍵,按摩椅處於開啟狀態; 再按此鍵,按摩椅關閉所有功能。



:按此鍵,可以暫停按摩程序; 再按此鍵,按摩椅程序繼續運行。

Θ

時間鍵:按此鍵,可調節按摩椅的按摩時間;3分鐘為一檔, 3-30分鐘可調,默認為15分鐘。

位置調節功能区:



: 按一次此鍵,按摩椅角度調到零重力1位置;按第二次此鍵,按摩椅角度 調整到零重力2位置;按第三次此鍵,按摩椅角度調整到零重力3位置; 按第四次止此鍵,按摩椅複位。 長按2秒为蓝牙开关控制。

零重力1→零重力2 → 零重力3 → 复位



: 搖擺功能開關鍵。



: 按一下此鍵, 按摩椅復位到初始狀態。





: 按住此鍵不放,可對背部位置單獨進行調節。

注,位置調節功能在拉筋功能開啟時無效。

自動程序功能区:

本按摩椅共設11套全身的自動按摩程序



脊柱骨骼



頸肩舒緩



深層全身



腰臀重點



元氣復蘇



舒展身心



塑形美態



輕鬆搖擺

減脂減重

活血循環

美膚美態

注:連續使用時,爲了不給身體增加負擔,休息間隙10分鐘。

手動程序功能区:

: 氣壓強度調節鍵,6檔可調。

: 機芯按摩速度調節鍵,6檔可調。

M : 本按摩椅共設5套手動按摩程序。

: 氣壓按摩位置選擇鍵,三档可调, 依次為腿部(L)一手部(H)一肩部(S)。

: 按此鍵可調節2個按摩球之間的間距,窄、中、寬3檔可調。 (燈常亮表示藍牙開,燈滅表示藍牙關)

: 按此鍵可開啟或關閉按摩椅的加熱按摩功能。

操作說明

APP安装

1. 适用于以下智能系统。







IOS 13

Android 10

Bluetooth 4.0

- 2. 开启蓝牙。
- 3. 手机连接网络(建议WiFi或4G),扫描下面二维码,下载安装ITSU WORLD 的APP。







IOS

APP界面和描述

打開APP,將顯示主頁菜單,請選擇您想要的功能,或者點擊屏幕下方頁面切換按鍵,進入另一綜合功能界面。





檢測





1.最新檢測。

2.檢測完成後,在8秒內,用戶可根據需求選擇微調肩部位置。也可直接按OK鍵,完成肩部位置確認。

自動模式





● 設置11種自動按摩程序,自动程序默认时间15分鐘。

操作說明





選擇"御手精選",進入4個特別設定的御手精選自動程序。

手動按摩模式



● 设有7种按摩模式: 揉捏1、揉捏2、敲打1、敲打2、指壓1、指壓2、推拿。

36

● 6檔按摩速度/力度可設置。

5. 附加









• 額外的功能全部顯示在附加這個界面下。

設置



- 4種語言可供選擇:繁體中文、英文、日文及馬來文。
- 業 藍牙功能開啟/關閉;
- 瓜) 按键聲音開啟/關閉。

操作說明

APP按鍵介紹

界面一:



- 1. 主頁返回鍵及顯示
- 2. 按摩狀態顯示
- 3. 按摩時間調整鍵及顯示,可選擇5、10、15、20、25以及30分鐘
- 4. 按摩程序快捷鍵
- 5. 按摩強度調整鍵及顯示,有6檔強度可選擇
- 6. 氣壓力度調整鍵及顯示,有6檔力度可選擇
- 7. 運行/暫停鍵

界面二:



- 1.椅背升降調節鍵
- 2.零重力功能調節键
- 3.搖擺功能選擇键 4.坐姿復位鍵

界面三:



- 1. 機芯上行/下行調節鍵 2. 定點按摩
- 3. 機芯幅度調節鍵
- 4. 按摩區域選擇鍵(僅手動模式)

手環同步





点击手环图标,将同步手环数据,同步成功后,将推送相应的按摩程序。當數據同步失敗時 (可能是因為藍牙未連接)會跳出提示頁面,這時請重新點擊手環圖標,重新同步數據。


操作說明

使用之後



- 1.關閉按摩椅回到初始位置。
- ●在調節按摩椅角度前,請確認周圍,特別注 意附近可能有小孩、寵物。
- 請確保手和腿遠離按摩椅的縫隙,避免可能造成

2.按下主開關(位於按摩椅後面)關機,將手控器 放回手控器袋。



- 3.關閉主開關並拔掉電源線插頭。
 - 請勿用拉扯電源線的方式拔插頭。
 - 請勿用濕手拔插頭。

功能特點

ITSU按摩椅通過電腦智能化控制,配合揉捏、捶打、指壓、拍打、推拿、脚滚和 氣壓功能等多種按摩手法及組合,針對各個穴位進行按摩,有效舒緩疲勞,促進新 成代謝及加强血液循環。

具備各種全身自動/手動按摩功能以符合您的各種要求。

除了精確的穴位按摩外,可同步進行各種按摩功能以形成特制按摩程序。

- 1. 根據人體工學設計,以提供更有效的按摩效果。
- 2. 定時功能將按照你的需求對按摩時間進行調整。
- 3. 手控器更易于操作。
- 4. 具備過熱過流保護,更加安全。
- 5. 操作是由微型智能處理器控制,使性能始終如一,卓越有效。
- 6. 本産品配有加熱功能,對熱不敏感者慎用。

清洗及保養

清潔合成皮革

使用柔軟的干布擦拭皮革。

- 切勿使用諸如稀釋劑、汽油、酒精等化學品清潔本機。
- 使用市面銷售的皮革保養品(抹布)時,請遵照其使用説明。
- 如果合成皮革特别髒,則通過以下方式擦拭。
 - 1、將軟布浸入水中或含3%至5%中性洗滌劑的熱水中, 然后 徹底摔干。
 - 2、使用上述軟布擦拭皮革表面。
 - 3、使用浸過清水且已徹底擰干的布料擦掉清潔液。
 - 4、使用檸干的軟布擦拭。
 - 5、使其自然風干。
- 難以去除污漬時,請將在市面上購買的三聚氰胺泡棉進入中性洗滌劑中,然后用它擦拭本機。
- 不要使用吹風機吹干表面。
- 由于布料的顏色會染到合成皮革的表面上,因此在使用生 仔布和彩色布料擦拭本機時務必小心。
- 不要使這些部件長時間與塑料接觸,因爲這會導致褪色。
- 合成皮革有變色的可能,所以在使用染發劑時,請將接觸的部分用毛巾覆蓋。









清潔塑料部位

- 1 將軟布浸入水中或含有中性洗滌 劑的熱水中,擰干后,擦拭本機 塑料部。
- 切勿使用諸如稀釋劑、汽油、酒精等化學 品清潔本機。
- **2** 使用浸有清水且已徹底擰干的布料擦拭。
- 擦拭遥控器前請務必擰干布料。
- 3 使其自然風干。









疑問解答(Q&A)

Q 因為生病而經常出入醫院的人可以 使用本產品嗎?

經常出入醫院的人,請在醫生商量 **八** 的前提下使用本產品。

按摩即所謂"觸壓刺激",即通過對肌肉進行壓迫, 緩解肌肉緊張,促進血液流動。根據不同的病因, 按摩有可能造成病情惡化,因此請務必在和主治醫 生商量之后使用本産品。

→ 身高多少的人適合使用本產品?

根據體型的不同多少會有所差异。請大 **A** 致參考下文使用產品。

● 身高小于145cm的用户,及身高超過185cm的用户 同時使用上半身按摩和小腿、脚部按摩時,可能 出現足底與脚部按摩部接觸不充分, 或膝蓋彎曲

身高較高的用戶感覺膝蓋部位彎曲時 請選擇下述方法△

▲ 放倒靠背,降低小腿、脚部按摩部位置。

身高較矮的用戶難以向下觸到足底按摩部時

請選擇下述方法▲

△ 抬起靠背、升高小腿、脚部按摩部位置。

搬家時,有什么需要特別注意的地方?

請注意一下事項。

A ・ 高工 トラマ。 ・ 為了方便搬運、請先將按摩椅靠背傾斜到最低位置 • 搬運時, 人不要坐在座椅上。

① 按下開機鍵,接通電源。

② 按下 () 使靠背呈完全傾斜狀態。

請長按這個按鈕, 直到 靠背和小腿停止移動。

- ③ 按下關機鍵,拔掉電源線。
- 在有原裝紙箱的情况下,請先確認電源綫未被 纏繞在本機上,將電源綫纏好放在座面上;搬 運的時候,請注意電源綫没有掉落且未與地面 發生摩擦。
- 在没有原裝紙箱的情况下,爲了防止機體劃傷 和搬運中的震動, 請妥善使用其他包裝輔材包 惠本品。

→ 有點在意按摩椅運作時發出的聲音......

按摩椅運作時產生的聲音,一般是由于機芯 **益** 構造而發出來的。

Q 按摩中感覺左右兩邊按摩輪的按摩力度 有差异,要緊嗎?

A 由于機心博坦,12.50年之 左右按摩輪的力度有差异。 由于機芯構造,在按摩過程中,確有可能感覺

爲了能够模擬出最自然的按摩手法, 本品機芯采用 了允許左右按摩輪交替捶背的機芯構造。在按摩過 程中、左右按摩輪接觸背部的具體位置可能稍有差 异,從而導致了使用者產生左右兩側按摩力度有所 不同的感覺。此時, 本品本身并未發生故障。

故障維修

發現故障后,首先檢查并嘗試—下方法。

如果在嘗試后,故障依然存在,請聯系銷售店。

問題

本使用本機過程中按摩輪停止

原因和處理方法

在使用過程中,按摩輸遇到過大的外力時,處于安全考慮, 按摩輪可能會停止移動。

如果按摩輪再次停止,請調整自己的坐姿,不要使背部完全貼在靠背上。 (應注意遵守相關注意事項,尤其在體重爲100kg或以上的 人使用時。)

不能傾斜 腿置臺不能升高降低 如果本機遇到了障礙物或者在使用本機時用力過大,處于 安全考慮,本機將停止工作。

當所有顯示的內容及按鈕在閃爍時, 且靠背或腿置臺已停止工作, 關閉本機電源一次,約10秒鐘后再次打"開啓"電源,然后操作本

按摩輪沒有達到肩部或頸部 的位置

如果頭部没有接觸到靠枕,或背部没有接觸到靠背,在體型檢測過 程中肩部位置可能低于實際位置。坐在座椅的最深位置,將頭部靠 在靠枕上, 然后從頭開始重新操作。

左右按摩輪的蓋度 (強度)

因爲搭載了可進行按摩輪交互捶拍動作的按摩機芯,出現這種情况 純屬自然, 并非機體故障。

本機根本無法運行。

● 電源綫連接已斷開。

● 没有打開本機電源開關

● 按下遥控器上的 □ 按鈕后,没有選擇任何程序。

背部都沒有溫熱感

● 温熱按鈕被設定爲關閉狀態。

● 温感的感知程度根據用户的提醒,按摩手法,衣服,室温而有所

按摩結束后,即使重新按下 □ 按鈕,也無法接通電源 ● 按摩結束后大約需要10秒鐘程序才終止。當所有運作均已停止后 至少等待10秒鐘, 然后再按 □ □ 。

本機已受損

電源綫或電源插頭异常發熱

爲防止事故發生,請務必與授權服務中心聯系。

故障維修


關于運行過程中本機發出的聲音和令人在意的感覺

在使用中會發生下述動作音、感覺,不過這是 <u>因按摩椅的結構而發生,并非异常。</u>

- 按摩輪由"伸出"改爲"收回"時的聲音
- 動作時按摩輪擦過面料上的皺紋時發出的聲音和感覺
- 揉按、捶拍動作等的動作音
- 按摩輪動作時的摩擦聲
- 上下運動時的動作音
- 傳送帶的轉動音
- 電機音
- 靠背傾斜時扶手與靠墊的摩擦聲
- 按摩輪與布料的摩擦聲
- 氣囊按摩運作時的充氣泵工作音
- 氣囊按摩運作時的排氣音
- 氣囊按摩運作時座椅下電磁閥發出的工作音。
- 腿置臺的晃動
- 肩部伸展、動作時的聲音
- 氣囊的動作音
- 脚部按摩的滑動音

當聲音變大時,也有可能發生了故障。

● 此時,請委托授權服務中心進行檢查和修理。



♠ 警告

● 請勿擅自改造本機。請勿自行分解或修理本機。 否則可能導致起火、异常動作、人身傷害。


⚠ 警告

- 發生异常、故障時,立即停止使用,拔掉電源 插頭。(否則可能冒烟、起火、觸電) <异常、故障事例>
- •接通電源開關后可能不動作
- •移動電源綫,有時通電有時不通電
- •運行中發出焦臭味、异常聲響
- •按摩椅變形或者异常發熱
- →請立即委托授權服務中心檢查和修理。

產品規格


電源		AC220-240V~,50/60Hz
消耗電力		100W
自動關閉		約30分鐘
尺寸	未傾斜時 (長 x 寬 x 高)	約 1420mm x 740mm x 1170mm
	傾斜時 (長×寬×高)	約 1650mm x 740mm x 920mm
重量		約65kg
包裝箱尺寸 (長×寬×高)		1590mm x 765mm x 875mm
重量(含包裝箱)		約78kg
使用環境		環境溫度:0°C~35°C 相對濕度:20%~80%
儲存環境		環境溫度:-5°C~35°C 相對濕度:20%~80%
用户最大體重		約120kg
進門尺寸		最小74CM





對於體重100kg或以上的人士,產品運作時可能產生更大的噪音而且面料外罩可能磨損得 更快。

產品規格



聯絡我們



ITSU World Sdn Bhd 13 Lorong Teknologi B. Nouvelle Industry Park. Taman Sains SG1 Kota Damansara. PJU 5. 47810 Petaling Jaya Malaysia

Tel: +603 6732 3722



ITSU World(HK) Limited
Workshop D1,28/F. TML Tower
No. 3 Hoi Shing Road, Tsuen Wan, N.T.

Tel: +852 3611 2228



PT Healthy World Lodan Center Block O No 20 Jalan Lodan Raya No 2 Jakarta Utara 14430

Tel: +62 21-6983 1123